LOW TEMPERATURE TENSILE DEFORMATION OF THIN FILMS*

G. DAS

IBM System Products Division, Hopewell Junction, New York 12533 (U.S.A.) (Received September 27, 1974)

Low temperature deformation of evaporated aluminum thin films has been investigated by means of a unique tensile testing apparatus developed for this purpose. The stress-strain curves under uniaxial tension show at least two distinct stages: (a) an elastic-like stage with a slope of approximately E/4 (stage I); and (b) a dynamic recovery stage with little or no work hardening (stage II). The total strain to fracture is about 0.07, and is apparently independent of temperature. The dynamic recovery stage has been analyzed in terms of vacancy or diffusion creep^{1, 2}, and is experimentally found to be very sensitive to the deposition conditions, grain size, strain rate and test temperature. At temperatures up to $375 \,^{\circ}$ K, grain boundary diffusion creep with an activation energy of 0.66 eV has been found to be the dominating process. At even higher temperatures (525 $\,^{\circ}$ K) volume diffusion creep with an activation energy of 1.40 eV predominates.

¹ F. R. N. Nabarro, Proc. Conf. on Strength of Solids, Phys. Soc., London, 1948, p. 75.

² C. Herring, J. Appl. Phys., 21 (1950) 437.

^{*} Abstract of a paper presented at the International Conference on Low Temperature Diffusion and Applications to Thin Films, Yorktown Heights, New York, U.S.A., August 12-14, 1974.